



garden and landscaping products

Assembly Instructions

WA – Westbury Arbour Seat

List of parts in fixings pack

Sub Assemblies

2 x Roof Sections

2 x Side Trellis Sections and Uprights

1 x Back Trellis Section

1 x Seat

1 x Seat Back

2 x Armrests

Fixings

6 x M8 x 95 Con. Bolts

6 x M8 Con Caps

8 x 90mm Screws

10 x 60mm Screws

12 x Screw Cups

2 x Allen Keys 5mm

4 x Rubber Bungs

Tools required (not provided)

1 x No.2 Pozidrive Screwdriver or a battery or electric drill with No.2 Pozidrive bit. This makes life easier, but is not essential



Your Arbour is in seven sub-assembled sections, two loose armrests, a bag of fixings and instructions. Some basic tools will be required to assemble the Arbour Seat.

1. On clean, level ground, assemble your Arbour Seat horizontally on the ground.
2. Slide the seat into position between the two Side Panels with the trellis flush to the outside. Line up the 11mm predrilled holes in the front Side Sections and Seat. The front of each trellis is defined by a small, pre-drilled hole in the trellis frame, 735mm from the base of the post. Push a cap in to the post and pass a 95mm long bolt through from the other side. Repeat for the other connection and tighten up with two Allen Keys provided.
3. Now, with help if necessary, lift this Assembly into a vertical position with the rounded ends of the Seat facing you. This will now be the front of your Seat.

When assembling, loosely bolt together until fully assembled then tighten all the bolts.

continued overleaf



garden and landscaping products

Assembly Instructions

WA – Westbury Arbour



4. The Seat Back is now slid into place between the now vertical Side Panels and the half lap joints on the Seat and Seat Back. Line up the 11mm predrilled holes and bolt up as you did the Seat.
5. Line up the rear Trellis panel with the Side Trellis panel at the top and screw into place, with the screws provided.
6. To position the arm rests, first locate the 4 small pre-drilled holes. They are located in the front of each side trellis frame and one on each side of the seat back. Next you will need to screw from the outer side of the pre-drilled hole in the trellis frame through into the front of the relevant arm rest using a 90mm screw and screw cup. Repeat for the other side. Using another two 90mm screws and screw cups, fix the arm rests into place by screwing through the pre drilled holes on the seat back into the back of the arm rests.
7. Join the two Roof Sections together, using 4 no. 90mm Woodscrews and 4 Screw Caps, ensuring the joint is as tight as possible, in the same way as the Centre Rail is fixed.
8. Slide the roof section over the half lap joints on the post. Centre the roof and fix with 4 no. 60mm screws & caps from the post into the roof on angle of 25°. The space between the posts at the front should be 118cm (1180mm).
9. All that is now left to do is check all the bolts and screws are reasonably tight, push rubber bungs into the holes above the front of the arm rests, and position, with help, your Northwood or Westbury Arbour in its selected position in your garden, and enjoy using it.

Hutton Garden and Landscaping Products

Church Lane, Northwood Green, Westbury-On-Severn, Gloucestershire GL14 1ND www.svw2000.co.uk/hutton

Tel: 01452 762089 Fax: 01452 762090 sales@hutton-ltd.co.uk