



garden and landscaping products

Assembly Instructions

WYE – Rectangular Picnic Table

List of parts in fixings pack

18 x 60mm Connecting Bolts

14 x 25mm Connecting Caps

2 x Allen Keys



When assembling, loosely bolt together until fully assembled then tighten all the bolts.

1. Place the table top upside down on a flat surface, taking care to protect the top from scratching.
2. Place leg set inside of the outer batten of the table top and bolt loosely through the three holes.
3. Place a diagonal brace between the leg set and the insert in the table top with the insert in the brace facing the leg. Bolt together loosely.
4. Repeat for the other leg set.
5. Now turn the table over and place the seat sections on the cross braces and loosely bolt. seat battens should be on the outside of each cross brace.
6. All that is left to do is tighten all of the bolts.

Hutton Garden and Landscaping Products

Church Lane, Northwood Green, Westbury-On-Severn, Gloucestershire GL14 1ND www.svw2000.co.uk/hutton

Tel: 01452 762089 Fax: 01452 762090 sales@hutton-ltd.co.uk